

Welcome to Lively®!

Thank you for choosing the Jitterbug® Flip. Our easiest cell phone ever connects you with our kind and knowledgeable team who can help day or night. Whether you want to learn more about your new phone, need a ride, have a health concern, or even need help in an emergency, enjoy peace of mind knowing you can count on us.

Enjoy step-by-step instructions in this user guide, and visit lively.com/support for the online user guide and additional learning resources.

Table of Contents

Section 1: Getting Started	1
Key Items in Your Box	2
Your Jitterbug Flip2	3
Charging the Battery	7
Turning Your Phone On (1st time)	9
Setting up Voicemail	10
Outside Screen Overview	11
Inside Screen Overview	12
Main Menu	13
Status Bar	15
Title Bar	17
Navigation Buttons	18
Section 2: Learning the Basics	19
Turning the Phone On/Off	20
Adding a Contact	20

Making a Call	23
Sending a Text Message	25
Taking a Photo	27
Setting Up Your Voicemail Greeting	29
Connecting to Wi-Fi	30
Calling Urgent Response	33

Section 3: Phone Calls 35

Phone Overview	36
Missed Calls	38
Voicemail	39
Contacts	40
Call History	42
Dial Number	43
Speed Dial	45
Speed Dial (continued)	46
Blocked Numbers	47
Answering or Ignoring a Call	50
Speakerphone	51

Adjusting the Call Volume	52
Adjusting the Ringer Volume	53

Section 4: Text Messages 55

Text Messages Overview	56
Reading and Replying to Text Messages	57
Sending New Text Messages	59
Checking Emergency Alerts	60
Typing Text Messages with the Keypad	61
Sending Photo Messages	65
Deleting Text Messages	66

Section 5: Photos & Videos 67

Photos & Videos Overview	68
Taking a Photo	69
Recording a Video	70
Viewing Your Photos and Videos	71
Deleting Your Photos and Videos	72
Sharing Your Photos	74

Saving Photos & Videos from Text Messages	76
Section 6: Amazon Alexa.....	77
Setting up Alexa.....	78
Setting up the Lively Skill.....	82
Using Alexa.....	88
Disabling Alexa.....	92
Section 7: Helpful Tools.....	93
Flashlight.....	94
Magnifier.....	95
Clock.....	96
Calculator.....	104
FM Radio.....	106
Reminders.....	108
Reminders (continued).....	109
Write My Own:.....	109
Reminders (continued).....	111
Reminder Library:.....	111

Mobile Support	113
Section 8: Changing Settings.....	115
Urgent Response Service	116
Volumes & Sounds	119
Notifications	128
Contacts Sort	130
Text Mode	131
Connecting to Wi-Fi.....	134
Turning Wi-Fi On & Off	136
Turning Airplane Mode On & Off	137
Connecting with Bluetooth	138
Turning Bluetooth On & Off.....	140
Accessibility.....	141
Flip to Answer.....	146
Tips	147
Emergency Alerts	148
Color Options.....	151
Screen Timeout.....	152


Screen Rotations.....	153
Turning Notification Badges On & Off	154
Voicemail:	155
Text Messages:.....	156
Reminders:.....	156
Section 9: Additional Information	157
Notification Pop-Ups	158
Brain Games	159
Getting Information About Your Phone	160
Additional Support	161
Contacting Us	162
Legal	163
Index.....	175

Section 1: Getting Started


Topics

- Key Items in Your Box
- Your Jitterbug Flip2
- Charging the Battery
- Turning Your Phone On (1st time)
- Outside Screen Overview
- Inside Screen Overview
- Main Menu
- Status Bar
- Title Bar
- Navigation Buttons

Key Items in Your Box




Jitterbug Flip2




Wall Charger

Charging Dock


Your Jitterbug Flip2




Your Jitterbug Flip2 (continued)



Your Jitterbug Flip2 (continued)



Your Jitterbug Flip2 (continued)




Charging the Battery

The phone's battery may be low when it is removed from its box. Charge the phone before use and whenever the battery is low so that the phone is ready when you need it.

1. Plug the Wall Charger into a wall outlet.
2. Plug the smaller end of the USB Cable into the side of the phone.

NOTE A USB cable can be purchased separately to charge your phone as well.




Charging the Battery (continued)

With the Charging Dock:

1. Plug the Wall Charger into a wall outlet.
2. Plug the smaller end of the USB Cable into the back of the Charging Dock.
3. Place the phone on the Charging Dock.


NOTE The front LED will flash red when the device battery is low and needs to be charged.




Turning Your Phone On (1st time)

1. Press and hold **On/Off** on the keypad and wait while the phone sets up.
2. Press **Ok** to review the Terms & Conditions.
3. Press **Down** to read the Terms & Conditions and **Ok** to accept them. You must review four screens.
4. When you finish, the phone's Main Menu is shown.

Step 2









Step 4




Setting up Voicemail

As a new Jitterbug Flip2 user, you need to set your voicemail PIN to receive voicemail messages. Make sure the PIN is at least 4 digits, easy to remember, but hard to guess.

1. From the **Main Menu**, press  or  to select **Phone** and press .
2. Press  or  to select **Voicemail** and press . The phone dials your voicemail.
3. Follow the prompts using the keypad to create a voicemail PIN and set up a voicemail greeting.


Outside Screen Overview

- A. Status Bar** – Shows you signal strength, wireless connectivity, Bluetooth and battery information.
- B. Date** – Shows the date.
- C. Current Time** – Displays the current time.
- D. Alerts** – Shows information about incoming and missed calls, voicemails and text messages.



Inside Screen Overview


- A. Status Bar** – Shows you signal strength, wireless connectivity, Bluetooth and battery information.
- B. Phone Number** – Shows your phone number.
- C. Title Bar** – Shows the name of the screen you are viewing.
- D. Menu** – Shows a list of the phone's options.



Main Menu


The Main Menu shows a list of all your phone's options. You can select an option to perform a task, including:

- A. Phone** – Make calls, see call history or check voicemail.
- B. Text Messages** – Read received messages and send texts.
- C. Contacts** – View or add a new contact.
- D. Amazon Alexa** – Set up Alexa to ask questions, get information, and more. (Optional)



Main Menu (continued)

- E. Photos & Videos** – View or capture photos or videos.
- F. Help Tools** – Access helpful tools, such as a flashlight, calculator, FM radio and more.
- G. Device Info** – View phone information, such as remaining battery, storage and signal strength.
- H. Settings** – Adjust sounds, notifications, colors and more.
- I. Games** – Play fun games that stimulate your brain.



Status Bar

The Status Bar at the top of your screen shows signal strength, wireless connectivity, Bluetooth status, battery and current time information.



- A. Cellular Signal Strength** – Affects your call quality. The more the triangle is filled in, the stronger your signal.
- B. Wi-Fi Status** – Shows the phone's Internet connection and signal strength.


Status Bar (continued)



- C. **Bluetooth Status** – Lets you know if you're connected to a Bluetooth device such as a car stereo or wireless headphones. Turn this feature on or off under Settings.
- D. **Battery Level** – Allows you to know how much battery you have left.
- E. **Current Time** – Shows the current time.





Title Bar


The Title Bar at the top of the menu shows the name of the screen you are viewing.



Navigation Buttons

At the top of your keypad you will find the six buttons that are used to navigate your phone.

- A. Directional Arrows** – Press , ,  or  to navigate through the phone's menus.
- B. Back** – Takes you one step back from your last action.
- C. Ok** – Confirms a selection.



Section 2: Learning the Basics

Topics

- Turning the Phone On/Off
- Adding a Contact
- Making a Call
- Sending a Text Message
- Taking a Photo
- Setting Up Your Voicemail Greeting
- Connecting to Wi-Fi
- Calling Urgent Response

Turning the Phone On/Off

1. Press and hold **On/Off**. The phone turns on or off.

Adding a Contact

2. From the Main Menu, press **Up** or **Down** to select **Contacts** and press **Ok**.
3. Press **Up** or **Down** to select **Add Contact** and press **Ok**.


Adding a Contact (continued)

4. Press **Up** or **Down** to select **First Name** and use the keypad to type the name.






See "Typing Text Messages with the Keypad" on page 61 for help typing a message.


5. Press **Up** or **Down** to select **Last Name** and use the keypad to type the name.

Step 5




Adding a Contact (continued)


6. Press  or  to select **Phone Number** and use the keypad to enter the number.
7. Press  or  to select **Save Contact** and press .

NOTE After a contact is saved, you can select their name in your phone menu Contacts and press  to call them.

Making a Call













Dialing a Phone Number:

1. Open the phone. The Main Menu displays.
2. Dial the 10-digit number on the keypad, and press  to call.












Making a Call (continued)


Calling an Existing Contact:

1. From the Main Menu, press  or  to select **Contacts** and press .
2. Press  or  to select a contact's name from the list and press .
3. Press  or  to select the phone number you want to call and press .
4. Press  or  to select **Dial Call** and press .





Sending a Text Message

1. From the Main Menu, press  or  to select **Text Messages** and press .
2. Press  or  to select **Compose New Text** and press .
3. Press  or  to select **New Number** or **From Contacts** and press .

Step 2




Sending a Text Message (continued)







4. Enter the 10-digit number or press  or  to select a contact from the list and press .
5. Type a message and press  to send.

See "Typing Text Messages with the Keypad" on page 61 for help typing a message.

Step 5




Taking a Photo

1. From the Main Menu, press  or  to select **Photos & Videos** and press .
2. Press  or  to select **Take Photo** and press .

Press  or  to select **Take Photo** for the rear camera, or **Take Selfie Photo** for the front (selfie) camera.

Step 2



Taking a Photo (continued)

3. Aim the camera and press **Ok** to take a picture.
4. Press **←** or **→** to select **Save** and press **Ok** to keep the picture.

NOTE In order to save photos to another device, a USB cord may be purchased separately.


Step 4


















Setting Up Your Voicemail Greeting

1. From the Main Menu, press **▲** or **▼** to select **Phone** and press **Ok**.
2. Press **▲** or **▼** to select **Voicemail** and press **Ok**. The phone dials your voicemail.
3. Enter your Voicemail PIN, then follow the prompts using the keypad to record your greeting.







Step 2




Connecting to Wi-Fi

1. From the Main Menu, press  or  to select **Settings** and press .
2. Press  or  to select **Wireless & Networks** and press .
3. Press  or  to select **Wi-Fi: Off** and press .
4. Press  or  to select **Wi-Fi: Off** and press .
5. Press  or  to select **On** and press .




Connecting to Wi-Fi (continued)

6. Press  or  to select **Available Networks** and press . The phone searches for available Wi-Fi networks and displays a list.
7. Press  or  to select the name of the Wi-Fi network you want to connect to and press .

Step 6




Connecting to Wi-Fi (continued)

- Use the keypad to type the Wi-Fi password, press  or  to select **Connect** and press . The phone connects to Wi-Fi.

See "Typing Text Messages with the Keypad" on page 61 for help typing a message.

TIP Select *Show Password* to see what you are typing.

Calling Urgent Response

Press the  Urgent Response button to get help in an unsafe or uncertain situation. (Access to Urgent Response Agents requires subscription to Urgent Response service).

There is a 6-second delay before you are connected to Urgent Response. This lets you cancel the call if you accidentally pressed the button.

NOTE If you accidentally call Urgent Response, please stay on the line and advise the Agent that it is not an emergency. Our Agents are notified of attempted calls, take each one seriously, and are trained to call back to confirm your situation.



Section 3: Phone Calls


Topics

- Phone Overview
- Missed Calls
- Voicemail
- Contacts
- Call History
- Dial Number
- Speed Dial
- Blocked Numbers
- Answering or Ignoring a Call
- Speakerphone
- Adjusting the Call Volume
- Adjusting the Ringer Volume

Phone Overview


Selecting Phone from the Main Menu shows you the following options:

- A. **Missed Calls** – See which calls you missed.
- B. **Voicemail** – Listen to voice messages from calls you missed.
- C. **Contacts** – Save phone numbers with a contact name for quicker dialing.




Phone Overview (continued)

- D. **Call History** – See your incoming and outgoing call history.
- E. **Dial Number** – Make a call by dialing the number.
- F. **Blocked Numbers** – See which numbers you have blocked from calling you.



Missed Calls

Missed Calls – Incoming calls that ended before you could answer.



Voicemail

Voicemail lets people leave audio recordings that you can listen to later if you miss a call. You will receive a notification on both the outside and inside screens when you have a voicemail. To access your voicemail:

1. From the Main Menu, select **Phone** and press **Ok**.
2. Select **Voicemail** and press **Ok**.
3. The phone calls your voicemail. Enter your voicemail PIN, then listen to the prompts and press the buttons on the keypad to access your messages.
4. When you are finished press **Back** or close your phone to hang up.

Contacts

Contacts is where you can save the phone numbers of your most frequently called contacts so that you don't have to manually dial their number each time.

To add a new contact:


1. From the Main Menu, select **Contacts** and press **Ok**.
2. Select **Add New Contact** and press **Ok**.
3. Select **First Name** and use the keypad to type the name.
4. Select **Last Name** and use the keypad to type the name.

Contacts (continued)

5. Select **Phone Number** and use the keypad to enter the number.
6. Select **Save Contact** and press **Ok**.

NOTE After a contact is saved, you can select their name in the contacts list and press **Ok** to call them.

Step 6




The screenshot shows a mobile phone interface for adding a contact. At the top, the status bar displays signal strength, Wi-Fi, and battery at 100% at 10:30 AM. Below the status bar is a dark header with the text 'Add Contact'. The main area contains two input fields: 'Last Name' with the text 'Doe' and 'Phone Number' with the text '5555551234'. At the bottom, there is a blue button with a right-pointing arrow and the text 'Save Contact', and below that, a white button with the text 'Add Optional Info.'.

Call History

From Call History you can view your inbound, outbound and missed call history. Select any record for more options like calling back and viewing caller details.

There are two call history records:


- **Inbound** – Incoming calls that were answered.
- **Outbound** – All outgoing calls that you made.



Dial Number

Dialing a Phone Number:

1. Open the phone. The Main Menu is shown.
2. Enter the 10-digit phone number and press **Ok** to dial.



Dial Number (continued)

Calling an Existing Contact:


1. From the Main Menu, select **Contacts** and press **Ok**.
2. Select a contact's name from the list and press **Ok**.
3. Select the phone number you want to call and press **Ok**.
4. Select **Dial Call** and press **Ok**.

Speed Dial


Storing the Speed Dial Number:

1. From the Main Menu, select **Contacts** and press **Ok**.
2. Select a contact's name from the list and press **Ok**.
3. Select **Edit Contact** and press **Ok**.
4. Select the phone number you want stored for speed dial and press **Ok**.
5. Select **Add to Speed Dial** and press **Ok**.


Step 2



Step 3



Step 5



Speed Dial (continued)

6. Select the number you want as the speed dial number and press **Ok**.
7. Select **Key #[number you chose]** and press **Ok**.
8. Select **Save Update** and press **Ok**.

Calling the Speed Dial Number:

Once the speed dial number is stored, simply flip open the phone and hold down the number to place calls to the contact.

Step 6



Step 7



Blocked Numbers


Blocked Numbers shows phone numbers that you have blocked from calling you. When you block a number, the phone will not ring, and calls will go directly to voicemail.

To block a number:

1. From the Main Menu, select **Phone** and press **Ok**.
2. Select **Call History** or **Missed Calls** and press **Ok**.

Blocked Numbers (continued)


3. Choose the number you want to block and press **Ok**.
4. Select **Block Number** and press **Ok**. The number is blocked.



Blocked Numbers (continued)

To unblock a number:

1. From the Main Menu, select **Phone** and press **Ok**.
2. Select **Blocked Numbers** and press **Ok**.
3. Select the number you want to unblock and press **Ok**.
4. Select **Unblock Number** and press **Ok**. The number is unblocked.



Answering or Ignoring a Call

Your phone will ring to notify you when someone is calling. The outside screen shows information available about the caller. Open the phone to answer or leave the phone closed to ignore the call. Ignoring a call will send the caller to your voicemail.

To answer or dismiss the call when the phone is already open:

- Select **Answer** to speak with the caller or **Ignore** to reject the call. Press **Ok**.

Speakerphone

While you are in a call, you can listen to the caller through either the earpiece speaker or the speakerphone.

The earpiece allows you to have a private conversation if you are in a public setting, while the speakerphone allows you to free your hands or allow other people surrounding you to participate in the conversation.

To switch between the earpiece speaker and speakerphone while on an active call:

- Press the Speaker button.




Adjusting the Call Volume

To adjust the call volume while on an active call:

- Press the upper end of the Volume Button to increase the call volume.
- Press the lower end of the Volume Button to decrease the call volume.

NOTE As you adjust the call volume, a menu appears to show the current volume level (Maximum, High, Medium or Low).



Adjusting the Ringer Volume

To adjust the ringer volume while viewing the Main Menu:

- Press the upper end of the Volume Button to increase the ringer volume.
- Press the lower end of the Volume Button to decrease the ringer volume.

NOTE As you adjust the ringer volume, a menu appears to show the current volume level (Maximum, High, Medium, Low or Silent).

See "Volumes & Sounds" on page 121 for instructions to lock Exterior Volume Buttons.

Section 4: Text Messages

Topics

- Text Messages Overview
- Reading and Replying to Text Messages
- Sending New Text Messages
- Checking Emergency Alerts
- Typing Text Messages with the Keypad
- Sending Photo Messages
- Deleting Text Messages

Text Messages Overview

Text Messages are a quick way to send short messages.

Select Text Messages from the Main Menu for the following options:

- A. Text History** – A list of text message conversations you have had and can reply to.
- B. Compose New Text** – Create a new text message.
- C. Emergency Alerts** – Shows any active emergency alerts in your area.
- D. Blocked Numbers** – see what numbers you have blocked from texting you.


Reading and Replying to Text Messages

1. From the Main Menu, select **Text Messages** and press **Ok**.
2. Select **Text History** and press **Ok**.
3. Select a contact or phone number and press **Ok**. Your conversation with that person opens.

Reading and Replying to Text Messages (continued)

4. Select **Respond** to reply to the message and press **Ok**.
5. Use the keypad to type a message and press **Ok** to send.

Step 4



Sending New Text Messages


1. From the Main Menu, select **Text Messages** and press **Ok**.
2. Select **Compose New Text** and press **Ok**.
3. Choose either **From Contacts** or **New Number** and press **Ok**.
4. Select the recipient from Contacts or enter the phone number.
5. Use the keypad to type a message and press **Ok** to send.

Checking Emergency Alerts

Emergency Alerts show active emergency alerts in your area. You will get a notification when the phone receives an emergency alert.

To check emergency alert messages:

1. From the Main Menu, select **Text Messages** and press **Ok**.
2. Select **Emergency Alerts** and press **Ok**.






Typing Text Messages with the Keypad


You can use the numeric keypad to enter numbers, letters and symbols to compose your text message.

Use these buttons to type a message on the phone's numeric keypad:

- **2-9** – Types numbers and letters.
- **Up**, **Down**, **Left** and **Right** **arrows** – Move over the typed letters.
- **Back** – Delete a character.
- **0** – Add a space.



Typing Text Messages with the Keypad (continued)


-  – Add a period.
-  – Displays a list of punctuation that you can select.
-  – Press repeatedly to cycle through the text entry modes (Quick Text, abc, Abc, ABC and 123).



Typing Text Messages with the Keypad (continued)

While typing a message, press  to choose one of these text entry modes:

- **Quick Text** (Predictive) – The phone predicts what word you are typing. Press the button with the letter you need once. When you're done typing a word, select the word you want with the  and  arrows.



Typing Text Messages with the Keypad (continued)


- **abc (All Lowercase)** – Press a button repeatedly to cycle through the letters. All letters are lowercase.
- **Abc (Initial Capitalized)** – Press a button repeatedly to cycle through the letters. The first letter is capitalized, and then the mode changes to “abc.”
- **ABC (All Capitalized)** – Press a button repeatedly to cycle through the letters. All letters are uppercase.
- **123 (Numeric)** – Types numeric characters only.

Sending Photo Messages

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Photo/Video Gallery** and press **Ok**.
3. Select a photo and press **Ok**.
4. Select **Photo Options** and press **Ok**.
5. Select **Share Photo** and press **Ok**.
6. Choose either **From Contacts** or **New Number**.
7. Select the recipient or enter the phone number.
8. Type a message and press **Ok** to send.

Deleting Text Messages

1. From the Main Menu, select **Text Messages** and press **Ok**.
2. Select **Text History** and press **Ok**.
3. Select a contact or phone number and press **Ok**. Your conversation with that person opens.
4. Select **Delete** and press **Ok**.
5. The phone confirms that you want to delete the message. Select **Delete** again and press **Ok**. The phone deletes the most recent text message.



Section 5: Photos & Videos

Topics


- Photos & Videos Overview
- Taking a Photo
- Recording a Video
- Viewing Your Photos and Videos
- Deleting Your Photos and Videos
- Sharing Your Photos
- Saving Photos & Videos from Text Messages

Photos & Videos Overview

The Camera allows you to take pictures and videos of precious moments and share with friends and family.

Select **Photos and Videos** from the Main Menu for the following options:

- A. Take Photo** – Capture a photo.
- B. Take Selfie Photo** – Capture a photo of yourself.
- C. Record Video** – Take a video of others.
- D. Record Selfie Video** – Take a video of yourself.
- E. Photo/Video Gallery** – View photos and videos you have captured or received.



Taking a Photo

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Take Photo** and press **Ok**.
3. Select **Rear Camera** or **Front Camera (Selfie)** and press **Ok**.
4. The photo you took is shown. Select **Save** or **Discard** and press **Ok**.

NOTE Press  to zoom in and  to zoom out.

Recording a Video

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Record Video** and press **Ok**.
3. Aim the phone toward the subject and press **Ok** to start recording.
4. When you are finished, press **Ok** to stop recording.
5. The video you took is shown. Select **Save** or **Discard** and press **Ok**.

Step 5



Step 7



NOTE Press **Up** to zoom in and **Down** to zoom out.

Viewing Your Photos and Videos

After you have captured a photo or video, you can view it by accessing the Photo/Video Gallery.

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Photo/Video Gallery** and press **Ok**.
3. Use the **Up**, **Down**, **Left** and **Right** arrows to navigate through the photos.
4. Select a photo or video and press **Ok** to view it.

Deleting Your Photos and Videos

While viewing your Photo/Video Gallery, you can delete any photos that you no longer need.

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Photo/Video Gallery** and press **Ok**.
3. Use the **Up**, **Down**, **Left** and **Right** arrows to navigate through the photos.
4. Select a photo or video and press **Ok** to view it.


Deleting Your Photos and Videos (continued)

5. Press **Ok** to open **Photo Options**.
6. Select **Delete Photo** or **Delete Video** and press **Ok**.
7. Select **Delete** again and press **Ok**.

Step 5



Step 6




Sharing Your Photos

Text the photos you take to other people.

1. From the Main Menu, select **Photos & Videos** and press **Ok**.
2. Select **Photo/Video Gallery** and press **Ok**.
3. Select a photo and press **Ok**.
4. Select **Photo Options** and press **Ok**.

Sharing Your Photos and Videos (continued)

5. Select **Share Photo** and press **Ok**.
6. Choose either **From Contacts** or **New Number**.
7. Select the recipient or enter the phone number.
8. Type a message and press **Ok** to send.



Saving Photos & Videos from Text Messages

1. From the Main Menu, select **Text Messages** press **Ok**.
2. Select **Text History** and press **Ok**.
3. Select a **contact or phone number** and press **Ok**. Your conversation with that person opens.
4. Press the up arrow to **highlight** the picture or video you want to save and press **Ok**.
5. Select **Photo/Video** Options and press **Ok**.
6. Select **Save to Gallery** and press **Ok**. You will get a confirmation that your photo/video has been Successfully Saved to Gallery.

Section 6: Amazon Alexa

Topics

- Setting up Alexa
- Using Alexa
- Setting up the Lively Skill
- Disabling Alexa


For additional resources, including how-to cards and videos, visit lively.com/fliplearn.

Setting up Alexa

Amazon Alexa gives you a way to easily navigate your phone with voice controls. Alexa is optional but can provide a better experience when using the phone.

1. From the Main Menu, select **Amazon Alexa** and press **Ok**.
2. Select **Set Up Alexa** and press **Ok**.

NOTE Connection of your Amazon account to Alexa on your Jitterbug Flip2 allows for personalized answers to questions like "Alexa, what is the weather forecast?" or "Alexa, what is the current time?" based on the location registered in your Amazon account.




Setting up Alexa (continued)

3. Select **Sign In To Amazon** and press **Ok**.

OR


Select **Skip Sign-In** and press **Ok**. Skip to step 8 on page 82.
(Create an Amazon account if you do not already have one.)

4. On a computer or tablet, go to amazon.com/us/code, log in to your Amazon account, and on the Register Your Device page enter the code that displays on your Jitterbug Flip2 phone screen.



Setting up Alexa (continued)

5. Wait while Amazon Alexa connects with your Amazon account. The **Connecting to Account** screen will display on your Jitterbug Flip2.
6. Press **Ok** on the Success screen to select **Next**.
7. To test Alexa, your Jitterbug Flip2 will prompt you to say "Alexa, how are you?" out loud. Alexa will respond to your question.
8. After testing Alexa, select **Skip to Using Alexa** and press **Ok**.
9. Press **Ok** to select **Next: Using Alexa**.



Setting up Alexa (continued)

10. Choose how you want to use Alexa and press **Ok**:


The "Just Ask Alexa" setting allows you to ask Alexa questions after simply flipping open the phone.

OR

The "Use From Menu" setting adds additional steps of pressing the Down arrow to highlight "Amazon Alexa" on the Main Menu and pressing **Ok** before you can ask Alexa questions.

11. The setup success screen displays. Press **Ok** to close.

Step 10



Setting up the Lively Skill

The Lively skill allows you to use your voice to:


- Make calls to contacts stored in your Jitterbug Flip2
- Help write and send text messages to contacts stored in your Jitterbug Flip2
- Check your Jitterbug Flip2 battery level
- Get your Jitterbug Flip2 phone number
- Find out how many minutes remain on your monthly plan
- Find out how many texts you have left on your monthly plan

Before you start, make sure you have set up Alexa and connected to your Amazon account.

Setting up the Lively Skill (continued)

1. Use a computer or tablet to go to [amazon.com](https://www.amazon.com) and sign into your Amazon account.
2. Click the "All" drop-down to the left of the search bar, select **Echo and Alexa** then select **Alexa Skills**.
3. Enter "Lively" into the search bar and press **Enter**.

Step 2



Setting up the Lively Skill (continued)

4. Select **Lively for Jitterbug Flip2** from the skill list and click **ENABLE** in the upper right corner.
5. The Lively account sign-in page opens. If you have already created a Lively account, sign in using your Lively account credentials. If you have not registered, click "Create an Account" and complete account registration.

NOTE If you don't know your passphrase, call customer service at 1.800.733.6632.

Step 4



Setting up the Lively Skill (continued)

6. The Name your devices page displays. Create a personal nickname to enter in the box under the phone number of your Jitterbug Flip2. Click **Submit**.
7. The page displays confirming the Lively skill has been successfully linked.

NOTE Alexa uses this nickname to identify the device. For example, with a nickname, Alexa can say "Jane's phone has 30 minutes remaining for this month" instead of "888.555.5555 has 30 minutes remaining for this month."

Setting up the Lively Skill (continued)

To confirm the Lively skill works correctly:

1. Make sure your phone is flipped open and say "Alexa, open Lively."
2. Lively skill: "Welcome to Lively! I don't recognize the device you're using. It's either new, or something has changed on it. When you created your account, you provided a name for each phone. This allows it to place calls or send a text. Is this a phone you want to set up to place calls or send texts?"
3. You say "Yes."
4. Lively skill: "Is this the phone for: <nickname you provided for your Jitterbug Flip2>?"

Setting up the Lively Skill • To confirm the Lively skill works correctly (continued):

5. You say "Yes."
6. Lively skill: "Alright! This phone is now assigned to <nickname>. Do you want to learn what you can do with Alexa on your phone?"
7. You say "Yes."

Using Alexa

Use Alexa to help navigate the phone or find answers to questions.

Ask Alexa a Question:

1. Open the phone.

OR

From the Main Menu, select **Amazon Alexa** and press **Ok**.

NOTE *If you're in a low signal area, connect to a Wi-Fi network for the best experience.*

Using Alexa • Ask Alexa a Question (continued):

2. To get started, simply ask a question. Start by saying the word “Alexa” for general questions.

“Alexa, what is the weather in Seattle?”

“Alexa, what time is it in Denver?”

“Alexa, set a timer for 1 minute.”

3. Alexa answers your question and returns you to the Main Menu.

NOTE *If you ask something that Alexa cannot do, Alexa will tell you that it is not supported.*

Using Alexa (continued)

Ask the Lively Skill:

The Lively skill helps you navigate and interact with your phone through Alexa.

Before using Alexa for Lively interactions, make sure you have completed Alexa and Lively skill setup. Note: If you're in a low signal area, connect to a Wi-Fi network for the best experience.

1. Open the phone.

OR

From the Main Menu, select **Ask Alexa** and press **Ok**.

Using Alexa • Ask the Lively Skill (continued):

2. To get started, just say "Alexa, ask Lively..."

You can ask the Lively skill for help with things like:

"Alexa, ask Lively to call Dr. Smith."

"Alexa, ask Lively to text Bill."

"Alexa, ask Lively how many minutes I have left."

3. Alexa answers your question and returns you to the Main Menu.

NOTE *Contacts must be entered into your phone to call or text with Alexa. When you access the Lively skill to place calls or write texts, Alexa will repeat the contact name back to you to confirm the correct contact is selected, then will place the call or ask you to speak your short text message. You can review and edit the text before you send the text.*

Disabling Alexa

If you want to stop using Alexa on your Jitterbug Flip2, follow these four steps to disable Alexa.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Amazon Alexa** and press **Ok**.
3. Select **Sign Out of Amazon** or **Disable Alexa** and press **Ok**.
4. Select **Sign Out of Amazon** or **Disable Alexa** and press **Ok** again to confirm.

NOTE *To use Alexa again, you must complete Amazon Alexa setup again.*

Section 7: Helpful Tools

Topics

- Flashlight
- Magnifier
- Clock
- Calculator
- FM Radio
- Mobile Support
- Reminders

Flashlight

The built-in flashlight helps you see in low light.

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Flashlight** and press **Ok**.
3. Select **On** and press **Ok**.
4. To turn off the flashlight, close the phone.

NOTE The flashlight automatically turns off after 15 minutes to save battery.

Magnifier

The magnifier tool uses the phone's camera to help you see small text or objects.

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Magnifier** and press **Ok**.
3. Aim the camera and press **Up** to zoom in and **Down** to zoom out.
4. Press **Ok** to Freeze or Unfreeze the image.

Step 3



Step 4



Clock

Set alarms and timers, or use the stopwatch to help keep track of time.


Set the Alarm Clock:

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Clock** and press **Ok**.
3. Select **Alarm** and press **Ok**.
4. Select **Set New Alarm** and press **Ok**.

Clock • Set the Alarm Clock (continued):

5. Enter the time you want the alarm to go off, using 3–4 digits. For example, enter “700” for 7:00 or “1100” for 11:00.
6. Select **AM** or **PM** and press **Ok**.
7. If you want the alarm to repeat, select **Yes** under *Repeat Alarm?* and press **Ok**. Select when you want the alarm to repeat and press **Ok**.


Step 5



Clock • Set the Alarm Clock (continued):

- To turn on the alarm, select **Yes** under *Make alarm active?* and press **Ok**.
- Select **Save Alarm** and press **Ok**.
- When the alarm rings, press **Ok** to turn the alarm off.

Step 9



Clock (continued)

Deleting an Alarm:


- From the Main Menu, select **Help Tools** and press **Ok**.
- Select **Clock** and press **Ok**.
- Select the alarm you want to delete and press **Ok**.
- Select **Delete Alarm** and press **Ok**.
- Select **Delete Alarm** again and press **Ok**.

Clock (continued)

Set the Timer:

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Clock** and press **Ok**.
3. Select **Timer** and press **Ok**.
4. Enter the time you want to count down, using 2 digits in the hour, minute and second fields. For example, enter “01” for 1.

Step 4



Clock • Set the Timer (continued):

5. Select **Start Timer** and press **Ok**.
6. When the time is up, the alarm rings. Press **Ok** to turn the alarm off.

Clock (continued)

Use the Stopwatch:

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Clock** and press **Ok**.
3. Select **Stopwatch** and press **Ok**.

Clock • Use the Stopwatch (continued):

4. Select **Start** and press **Ok**. The stopwatch starts.

To pause, select **Stop** and press **Ok**. Select **Resume** and press **Ok** to start the stopwatch again.

To track laps, select **Lap** and press **Ok**. The lap times are shown at the bottom of the screen.

To reset the time, select **Reset** and press **Ok**.

Calculator

The calculator helps you add, multiply, subtract and divide.


1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Calculator** and press **Ok**.
3. Type the first number.

Calculator (continued)

4. Use the arrows to add an addition (**Up**), subtraction (**Down**), division (**Left**) or multiplication (**Right**) sign.
5. Type the second number.
6. Press **Ok** to calculate the total.

NOTE Press **$\frac{1}{x}$** to enter a decimal. Press **Back** to delete a character.

Step 4




Step 6



FM Radio

1. Connect headphones to the 3.5mm audio jack on the side of the phone.
2. From the Main Menu, select **Help Tools** and press **Ok**.
3. Select **FM Radio** and press **Ok**.
4. To navigate through or save channels:
To find available stations, press **◀** or **▶**

Step 4



FM Radio (continued)

To save a station as a favorite, select **Add as Favorite** and press **Ok**.

To type in a station number with the keypad, select **Enter Station Numbers** and press **Ok**. Do not enter the decimal. For example, enter “933” to tune to 93.3.

To choose a station you saved, select **Favorite Stations** and press **Ok**.

Use the phone's volume buttons to raise or lower the volume.

NOTE While the radio is playing, *Now Playing on Radio* appears on the Main Menu for quick access to the radio settings.

Reminders

1. From the Main Menu, select **Help Tools** and press **Ok**.
2. Select **Add Reminder** and press **Ok**.
3. You will have an option to use suggested Reminder titles from the **Reminder Library** or **Write My Own**. Select an option and press **Ok**.

Reminders (continued)

Write My Own:

1. Enter a Description or Details for the timer using the keypad.
2. Use the down arrow key to highlight the Reminder Time.
3. Enter the time you want for the Reminder, using 2 digits in the hour, minute and second fields. For example, enter "01" for 1.
4. Use the down arrow key to select either **AM** or **PM** and press **Ok**.
5. Use the down arrow key to select Day(s) of the week and press **Ok**.
6. If you would like to add images to your Reminder, use the down arrow key to select **Add Images** (Max 2) and press **Ok**.

Reminders • Write My Own (continued):

7. The camera will open. Press **Ok** to Capture Image.
8. Select **Save** and press **Ok** to save image.
9. Select **Discard** and press **Ok** if you would like to take another image.
10. Use the **(Down)** key to Select **Save Reminder** to Save.

Reminders (continued)

Reminder Library:

1. Select one of the preset Reminders and press **Ok**.
2. Use the **(Down)** key to highlight the Reminder Time.
3. Enter the time you want for the Reminder, using 2 digits in the hour, minute and second fields. For example, enter “01” for 1.
4. Use the down Arrow key to Select either **AM** or **PM** and press **Ok**.
5. Use the **(Down)** key to Select Day(s) of the week and press **Ok**.
6. If you would like to add images to your Reminder, use the **(Down)** key to select **Add Images (Max 2)** and press **Ok**.

Reminders • Reminder Library (continued):

7. It will open the Camera, press **Ok** to Capture Image.
8. Select **Save** and press **Ok** to save image.
9. Select **Discard** and press **Ok** if you would like to take another image.
10. Use the **(Down)** key to Select **Save Reminder** to Save.

Mobile Support

Mobile Support lets the Lively team help you remotely with problems on the phone.

- If you have questions, call us toll-free at:
1.800.733.6632

Section 8: Changing Settings

Topics

- Urgent Response Service
- Volumes & Sounds
- Notifications
- Flip to Answer
- Contacts Sort
- Text Mode
- Connecting to Wi-Fi
- Turning Wi-Fi On & Off
- Connecting with Bluetooth
- Turning Bluetooth On & Off
- Accessibility
- Tips
- Emergency Alerts
- Color Options

Urgent Response Service


The Urgent Response button on your Jitterbug Flip2 gives you access to our exclusive Lively® Urgent Response Service. This service provides easy-to-use and reliable access to certified Urgent Response Agents who will confirm your location, evaluate your situation, and get you the help you need.

To enable or disable the Urgent Response button:


1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Urgent Response** and press **Ok**.
3. Select **Enable** or **Disable** and press **Ok**.

Urgent Response Service (continued)

To Place an Urgent Response Call:

- Press the  button to call Urgent Response in an uncertain or unsafe situation.

The phone counts down aloud and on-screen before the call is placed. If you need to cancel the call, press **Ok**.



Urgent Response Service • To Place an Urgent Response Call (continued):

4. If the  button is disabled, dial  +  (5*) and press  for an Urgent Response Agent.






NOTE *If you accidentally call Urgent Response, please stay on the line and advise the Agent that it is not an emergency. Our Agents are notified of attempted calls, take each one seriously, and are trained to call back to confirm your situation.*

- Dial 9-1-1 in case of emergency.

Volumes & Sounds

Adjust the volume and sounds that the phone makes.

Changing the Ring Tone:

1. From the Main Menu, select **Settings** and press .
2. Select **Volumes & Sounds** and press .
3. Select **Sounds** and press .
4. Select **Ring Tone** and press .
5. Select a ring tone from the list and press .

Volumes & Sounds (continued)

Adjusting the Ring Tone Volume Level:

1. Open the phone. The Main Menu is shown.
2. Press the volume buttons on the side of the phone. The Ring Tone Volume screen shows the current volume level.



Volumes & Sounds (continued)

Turning Keypad Sounds On or Off:

When keypad sounds are turned on, the phone makes a sound when you press a button.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Volumes & Sounds** and press **Ok**.
3. Select **Sounds** and press **Ok**.
4. Select **Key Tone** and press **Ok**.
5. Select **On** or **Off** and press **Ok**.

Volumes & Sounds (continued)

Adjusting the Call Volume Level:

You can raise or lower the speakerphone, earpiece or headphone volume level while on a call. To adjust the volume:


- Press the volume buttons on the side of the phone. A screen shows the current volume level.

Volumes & Sounds (continued)

Adjusting the Headphone Volume Level:

You can adjust the headphone volume while listening to the radio, a call or other audio. To adjust the headphone volume:

- Press the volume buttons on the side of the phone. A screen shows the current volume level.



Volumes & Sounds (continued)

Adjusting the Alarm Volume Level:

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Volumes & Sounds** and press **Ok**.
3. Select **Volumes** and press **Ok**.
4. Select **Alarm** and press **Ok**.
5. Select a volume level (**Low, Medium, High** or **Maximum**) and press **Ok**.

Volumes & Sounds (continued)

Locking the Exterior Volume Buttons:

You can turn off (or lock) the volume buttons on the side of the phone if you keep accidentally pressing them.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Volumes & Sounds** and press **Ok**.
3. Select **Volumes** and press **Ok**.
4. Select **Lock Buttons** and press **Ok**.
5. Select **Yes** to lock the volume buttons or **No** to unlock them and press **Ok**.

Volumes & Sounds (continued)

Adjusting Volume Levels with Locked Volume Buttons:


If the exterior volume buttons are turned off, you can adjust the volume in the Settings menu:

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Volumes & Sounds** and press **Ok**.
3. Select **Volumes** and press **Ok**.

Volumes & Sounds • Adjusting Volume Levels with Locked Volume Buttons (continued):

4. Select what you want to change the volume of and press **Ok**.
You can change the volume of:
 - **Ring Tone/Vibration**
 - **Speakerphone**
 - **Earpiece**
 - **Headphone**
 - **Alarm**
5. Select a volume level and press **Ok**.

Step 4



Notifications

Choose whether to be notified when you receive text messages or voicemails.

Turning Text Message Notifications On or Off:


1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Notifications** and press **Ok**.
3. Select **Text Messages** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

Notifications (continued)

Turning Voicemail Notifications On or Off:

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Notifications** and press **Ok**.
3. Select **Voicemail** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.


Step 3



Contacts Sort

Select how your contacts are sorted in the Contacts list.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Contacts Sort** and press **Ok**.
3. Select by **First Name** or by **Last Name** and press **Ok**.



Text Mode


You can choose the default text entry mode that the phone uses.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Text Mode** and press **Ok**.
3. Choose the text entry mode you want to use and press **Ok**.

You can select:

Quick Text (Predictive) – The phone predicts what word you are typing. Press the button with the letter you need once. When you're done typing a word, select the word you want with the **←L** and **R→** arrows.

Step 3




Text Mode (continued)

- **abc** (All Lowercase) – Press a button repeatedly to cycle through the letters. All letters are lowercase.
- **Abc** (Initial Cap.) – Press a button repeatedly to cycle through the letters. The first letter is capitalized, and then the mode changes to “abc.”

Text Mode (continued)

- **ABC** (All Capitalized) – Press a button repeatedly to cycle through the letters. All letters are uppercase.
- **123** (Numeric) – Types numeric characters only.

NOTE While typing text, you can temporarily change the text entry mode by pressing .

Connecting to Wi-Fi

Make wireless connections with your phone.


1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Wireless & Network** and press **Ok**.
3. Select **Wi-Fi** and press **Ok**.
4. Select **Available Networks** and press **Ok**. If Wi-Fi is off, select “Turn on Wi-Fi” and press **Ok**. The phone searches for available Wi-Fi networks and displays a list.

Connecting to Wi-Fi (continued)


5. Select the name of the Wi-Fi network you want to connect to and press **Ok**.
6. Enter the Wi-Fi password, select **Connect** and press **Ok**. The phone connects to Wi-Fi.

NOTE Select **Show Password** to see what you are typing.

Step 5



Step 6



Turning Wi-Fi On & Off

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Wireless & Networks** and press **Ok**.
3. Select **Wi-Fi** and press **Ok**.
4. Select **Wi-Fi** again and press **Ok**.
5. Select **On** or **Off** and press **Ok**.

Turning Airplane Mode On & Off

When traveling on an airplane, you may be required to put your phone in Airplane Mode. In Airplane Mode, you cannot make or receive calls (including Urgent Response), or texts.

1. From the **Main Menu**, select **Settings** and press **Ok**.
2. Select **Wireless & Networks** and press **Ok**.
3. Select **Airplane Mode** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

Connecting with Bluetooth

Bluetooth allows you to connect wirelessly to devices such as car stereos, portable speakers and wireless headphones. To connect to a Bluetooth device:

1. Turn on the Bluetooth device you want to connect to and put it in Bluetooth pairing mode. See the instructions that came with the device for more information.
2. From the Main Menu, select **Settings** and press **Ok**.
3. Select **Wireless & Networks** and press **Ok**.

Connecting with Bluetooth (continued)

4. Select **Bluetooth** and press **Ok**.
5. Select **Pair New Device** and press **Ok**. The phone searches for nearby devices and lists them.
6. Select the Bluetooth device you want to connect to and press **Ok**. The phone pairs to the Bluetooth device.

Step 5



Step 6



Turning Bluetooth On & Off

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Wireless & Networks** and press **Ok**.
3. Select **Bluetooth** and press **Ok**.
4. Select **Bluetooth** again and press **Ok**.
5. Select **On** or **Off** and press **Ok**.

Accessibility

The Accessibility settings let you customize settings to make it easier to use the phone.

Changing the Text Size:

You can increase the Text Size the phone uses to make it easier to read.


1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **Text Size** and press **Ok**.
4. Select **Regular (default)** or **Extra Large** and press **Ok**.

Accessibility (continued)

Turning Read Out On or Off:

Turning on Read Out sets the phone to read screen content out loud to you.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **Read Out** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.



Accessibility (continued)

Turning Real Time Text (RTT) On or Off:

Real Time Text lets you use text to communicate during a phone call.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **RTT** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

NOTE To use RTT, select a phone number from the Contacts list, select **Use RTT** and press **Ok**.

Accessibility (continued)

Turning Hearing Aid Compatibility On or Off:

Turning on Hearing Aid Compatibility (HAC) makes the phone compatible with hearing aids during phone calls.


1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **HAC** and press **Ok**.
4. Select **On** if you use hearing aids or **Off** if you do not and press **Ok**.

Accessibility (continued)

Changing the Phone's Language:

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **Language** and press **Ok**.
4. Select **English** or **Español** and press **Ok**.

Step 4



Flip to Answer

Disabling Flip to Answer:

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **Answer on Flip Open: On** and press **Ok**.
4. Select **Off** and press **Ok**.

Tips

Tips shows helpful information about how to navigate and use the phone.

1. From the **Main Menu**, select **Settings** and press **Ok**.
2. Select **Accessibility** and press **Ok**.
3. Select **Tips** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

Emergency Alerts

Emergency Alerts show active emergency alerts in your area. You can choose the kinds of alerts you receive on the phone.


Selecting the Types of Emergency Notifications:

1. From the Main Menu, select **Notifications** and press **Ok**.
2. Select **Emergency Alerts** and press **Ok**. A menu of emergency alert types is shown, including:
 - **Extreme**
 - **Severe**

Emergency Alerts • Selecting the Types of Emergency Notifications (continued):

- **AMBER Alerts**
 - **RMT (Required Monthly Test) Alerts**
 - **Public Safety**
 - **State/Local Test**
3. Select an emergency alert and press **Ok**.
 4. Select **On** if you want to receive that type of alert or **Off** and press **Ok**.

Step 2



Emergency Alerts (continued)

Changing How Emergency Alerts are Received:


1. From the Main Menu, select **Notifications** and press **Ok**.
2. Select **Emergency Alerts** and press **Ok**.
3. Toward the bottom of the screen, select **Vibrate Alert** or **Audio Alert** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

Color Options

You can customize the color the phone uses to highlight a menu item for screen navigation.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Screen** and press **Ok**.
3. Select **Highlight Color** and press **Ok**.
4. Select the color the phone should use when highlighting a menu item and press **Ok**.

Step 4



Screen Timeout

Time the screen turns off to save battery power.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Screen** and press **Ok**.
3. Select **Screen Timeout** and press **Ok**.
4. Select the amount of time you would like before the screen turns off and press **Ok**.

Screen Rotations

Changes screen orientation in camera and gallery when device is flipped.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Screen** and press **Ok**.
3. Select **Screen Rotation** and press **Ok**.
4. Select **On** or **Off** and press **Ok**.

Turning Notification Badges On & Off

Choose whether to be shown notification badges when you receive missed calls, text messages, voicemails or Reminders.

1. From the Main Menu, select **Settings** and press **Ok**.
2. Select **Notifications** and press **Ok**.
3. Select **Badges** and press **Ok**.

Turning Notification Badges On & Off (continued)

Missed Calls:

1. Select **Missed Calls** and press **Ok**.
2. Select **On** or **Off** and press **Ok**.

Voicemail:

1. Select **Voicemail** and press **Ok**.
2. Select **On** or **Off** and press **Ok**.

Turning Notification Badges On & Off (continued)

Text Messages:

1. Select **Text Messages** and press **Ok**.
2. Select **On** or **Off** and press **Ok**.

Reminders:

1. Select **Reminders** and press **Ok**.
2. Select **On** or **Off** and press **Ok**.

Section 9: Additional Information

Topics

- Notification Pop-Ups
- Brain Games
- Getting Information About Your Phone
- Contacting Us

Notification Pop-Ups

You must select an option for the screen to go away, the back button will not remove the screen. There are 2 ways to get the Notification Pop up for Missed calls, Texts and Voicemails.

While the phone is on and you receive a new notification, there is a notification pop up. When you power on the phone and you have notifications that have not been acknowledged yet.

1. Select **Texts** and press **Ok** to view Text messages.
2. Select **Voicemail** and press **Ok** to listen to new Voicemails.
3. Select **Missed calls** and press **Ok** to view Missed calls.
4. Select **Close** and press **Ok** to go back to Main Menu.

Brain Games

The phone has fun brain-training games to help improve your memory and navigation.

1. From the Main Menu, select **Games** and press **Ok**.
2. **Eye for Detail** – Work out your memory for better recall later. Briefly view a series of 3-5 images on the screen and then match where identical images appeared.
3. **Right Turn** – Exercise your spatial rotation skills to improve navigation. View two images side by side and decide if they are the same or if they are mirror images.
4. **To-Do List Training** – Exercise your short-term memory. Review a set of instructions, and use your memory to follow them in order.

Getting Information About Your Phone

1. From the Main Menu, select **Device Info** and press **Ok**.
2. Select **Device Info** and press **Ok**. A menu of available device information is shown, including information about:

- Phone Usage (Minutes and Texts Used)
- About Device
- Device Storage
- Battery
- Signal
- Legal Info

3. Select a category that you want more information about and press **Ok**.

Additional Support

At Lively, we provide you with easy-to-follow educational tools for the way you want to learn. Whether you want to learn the basics or are ready for advanced features, we're here to help every step of the way. Go to lively.com/support to access additional educational tools to make you a Jitterbug Flip2 expert.

There you'll find:

- Frequently Asked Questions
- How-to Videos
- How-to Cards
- And more!

Contacting Us

If you have any questions or comments, we're here to help:

- Send us an email at:
customercare@lively.com
- Call us toll-free at:
1.800.733.6632
- Write to us at:
Lively Customer Service
P.O. Box 4428
Carlsbad, CA 92018

Legal

Customer Agreement

BY USING THE PHONE AND LIVELY SERVICES, YOU ARE AGREEING TO BE BOUND BY THE CUSTOMER AGREEMENT. TO REVIEW THE MOST CURRENT VERSION OF THE CUSTOMER AGREEMENT, WHICH GOVERNS YOUR USE OF THE PHONE AND LIVELY SERVICES, PLEASE VISIT WWW.LIVELY.COM/LEGAL/CUSTOMER-AGREEMENT.

Arbitration Agreement, Class Action Waiver, Jury Waiver, and Forum Selection Clause

BY USING THE PHONE AND LIVELY SERVICES, YOU ARE AGREEING TO BE BOUND BY OUR ARBITRATION AGREEMENT, CLASS ACTION WAIVER, AND FORUM SELECTION CLAUSE IN THE CUSTOMER AGREEMENT. TO REVIEW THE MOST CURRENT VERSION OF THIS CLAUSE, PLEASE VISIT WWW.LIVELY.COM/LEGAL/CUSTOMER-AGREEMENT.

Limited Warranty

To View Our Standard Limited Warranty for Lively products, please visit <https://www.lively.com/legal/warranty>.

Privacy Policy

If you would like to learn more about our privacy practices, please visit <https://www.lively.com/legal/privacy-policy>.

If you would like to learn more about your rights under individual state laws, please visit <https://www.lively.com/legal/states-rights-privacy-policy>.

Health And Safety Statement

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY:

Given that studies show that using a phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their phone when the vehicle is not parked. Check the laws and regulations on the use of wireless phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

CONDITIONS OF USE:

You are advised to switch off the phone from time to time to optimize its performance.

Remember to abide by local authority rules of mobile phone use on aircrafts.

If your phone is a unibody device, where the back cover and battery are not removable, disassembling the phone will void your warranty. Disassembling the phone can cause bodily injury if the battery is punctured.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental conditions, such as moisture, humidity, rain, infiltration of liquids, dust, sea air, etc. The manufacturer's recommended operating temperature range is -20°C (-4°F) to +60°C (140°F).

At over 55°C (131°F), the legibility of the phone's display may be impaired, though this is temporary and not serious.

Do not open, dismantle, or attempt to repair your phone yourself.

Do not drop, throw, or bend your phone.

Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your phone model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Your phone should not be disposed of in a municipal waste.

Please check local regulations for disposal of electronic products.

Remember to make backup copies or keep a written record of all important information stored on your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, orientation, or movements.

PRIVACY:

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your phone regarding taking photographs and recording sounds with your phone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization has been obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your phone (including the carrier) disclaim any liability which may result from improper use of the phone.

BATTERY:

For non-unibody device, where the battery is removable:

- Do not attempt to open the battery due to the risk of toxic fumes and burns;
- Do not puncture, disassemble, or cause a short circuit in a battery;
- Do not burn or dispose of a used battery in the garbage or store it at temperatures above 60°C (140°F).
- Batteries must be disposed of in accordance with locally applicable environmental regulations.
- Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCL Communication Ltd. and/or its affiliates.

For unibody device, where the battery is not removable:

- Do not attempt to eject, replace, or open battery;
- Do not puncture the back cover of your phone;
- Do not burn or dispose of your phone in the garbage or store it at temperatures above 60°C (140°F).

Phone and battery as a unibody device must be disposed of in accordance with locally applicable environmental regulations.



This symbol on your phone, the battery, and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment;
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

In non-European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at <http://www.gowirelessgogreen.org/>

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

CHARGERS:

Home A.C./ Travel chargers will operate within the temperature range of: -10°C (14°F) to 50°C (122°F).

The chargers designed for your phone meet the standard for safety of information technology equipment and office equipment use.

Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction.

They should be used for this purpose only.

Characteristics of power supply (depending on the country):

Travel charger: Input: 100-240 V, 50/60 Hz, 200 mA

Output: 5V, 1A

Battery: Lithium 1780 mAh

Radio waves

THIS PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the phone transmitting at its highest certified power level in all tested frequency bands.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching for FCC ID: 2ACCJN064 for 4058P.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone. Before a phone model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for 4058P when tested is 0.66W/Kg for use at the ear and 1.12W/Kg for use close to the body.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for RF exposure.

For body-worn operation, the phone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 15 mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.ctia.org/>

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep phones away from the head and body. Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected;
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Your phone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with a headset or usb data cable.

If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 15 mm away from the body.

Please note by using the device some of your personal data may be shared with the main device. It is under your own responsibility to protect your own personal data, not to share with it with any unauthorized devices or third party devices connected to yours. For products with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your product as a hotspot (where available), use network security. These precautions will help prevent unauthorized access to your device. Your product can store personal information in various locations including a SIM card, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example against unauthorized or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- The technical possibilities available;
- The costs for implementing the measures;
- The risks involved with the processing of the personal data, and;
- The sensitivity of the personal data processed.

You can access, review and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

US Information Concerning the Federal Communications Commission (“FCC”) Requirements for Hearing Aid Compatibility with Wireless Devices

When wireless devices are used near hearing devices (such as hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference, and wireless devices also vary in the amount of interference that they generate.

The wireless telephone industry has developed ratings to assist hearing device users in finding wireless devices that may be compatible with their hearing devices. Not all wireless devices have been rated. Wireless devices that are rated will have the rating displayed on the box together with other relevant approval markings.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device is vulnerable to interference, you may not be able to use a rated wireless device successfully. Consulting with your hearing health professional and testing the wireless device with your hearing device is the best way to evaluate it for your personal needs.

HAC rating (ANSI 2011): M4/T4

This phone has been tested and rated under the American National Standard Institute (ANSI) C63.19-2011 hearing-aid compatibility standard. The ANSI standard for hearing-aid compatibility contains two types of ratings:

M: For reduced radio-frequency interference to enable acoustic coupling with hearing aids that don't operate in telecoil mode

T: For inductive coupling with hearing aids operating in telecoil mode

A phone is considered hearing-aid compatible if it is rated M3 or M4 for acoustic coupling and T3 or T4 for inductive coupling.

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from wireless devices.

For more information about the actions that the FCC has taken with regard to hearing-aid compatibility with wireless devices and other steps that the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, visit www.fcc.gov/cgb/dro.

FCC ID: 2ACCJN064 for 4058P.



www.sar-tick.com



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on **Radio waves** section.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 15 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your phone near your ear while the loudspeaker is in use.

Frequency Stability

The product meets Section 15.407(g) requirements from KDB 789033 D02v02r01. The emissions are maintained within the band of operation under all conditions of normal operation.

- a) Do not disassemble or open crush, bend or deform, puncture or shred
- b) Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- c) Only use the battery for the system for which it is specified
- d) Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- e) Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- f) Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

Only authorized service providers shall replace battery. (If the battery is non-user replaceable).

- g) Promptly dispose of used batteries in accordance with local regulations
- h) Battery usage by children should be supervised.
- j) Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- k) Improper battery use may result in a fire, explosion or other hazard.

Index

Symbols

3.5mm audio jack 4, 108

A

Accessibility

phone reads content 143

Accessibility settings 142

adding

Contacts 21, 22

alarm clock

adjusting volume 126

deleting alarm 101

setting alarm 98

Alerts 10

Alexa

Disabling 94

setting up 80

using 90

Amazon Alexa

Main Menu 12

Answering Calls 50

Arrows

directional 6

navigation 6, 17

audio jack 108

3.5mm 4

B

Back button 6, 17

text messages 61

basics

adding contacts 21, 22

calling a contact 24

connecting to Wi-Fi 30

learning 19

making a Call 23

sending text messages 25

taking photos 27

turning phone on/off 20

voicemail greeting 29

battery

charging 7

charging with Charging Dock 8

charging with USB cable 7

level 15

status bar 15

Blocked Numbers 46, 47

Bluetooth

connecting 139

status 15

Brain Games 162

button

back 6, 17

in text messages 63

navigation 17

Ok 6, 17

Power 5

Speakerphone 5, 6

Urgent Response 5, 6

volume 3

C

Calculator 106

Call History

inbound calls 42
outbound calls 42
viewing 42

Calling Speed Dial 46

calls

answering 50
contacts 24
ignoring 50
missed 38
rejecting 50

call volume

adjusting 122

camera

deleting photos 73
deleting videos 73
front 5, 69, 70

rear 3, 69, 70
saving photos 77
saving videos 77
Selfie 5
taking photos 69

Cellular Signal Strength 14

Changing Language 146

Changing the Text Size 142

Charging

dock connectors 3
charging the battery 8
Wall 2

Charging Connectors 3

charging the battery 7

checking Emergency Alerts 60

clock

deleting alarm 101
setting alarm 98
setting timer 102
using stopwatch 104

Color Options 152

connecting

to Bluetooth 139
to Wi-Fi 30, 136

contacts

adding 20, 40
calling 24, 44
Main Menu 12
sorting 132

Current Time 10, 15

D

date 10

deleting

photos 73
text messages 66
videos 73

Device Info

Main Menu 13

dialing phone numbers 23, 43

directional arrows 6

Disabling Flip to Answer 147

E

earpiece 5

adjusting volume 124

Emergency Alerts 60

receiving modes 151
selecting types 149

F

Flashlight 96

Flip to Answer 147

FM radio 108

front camera 5

G

games

Eye for Detail 162
Main Menu 13, 162
Right Turn 162

H

headphone

adjusting volume 124

Hearing Aid

turning on/off 145

help

contact information 165

Help Tools

alarm clock 98
Calculator 106
Flashlight 96
FM Radio 108
Magnifier 97
Main Menu 13, 96, 97, 98, 101,
102, 104, 106, 108, 110
stopwatch 104
timer 102

highlighting color options 152

I

information

battery 163
device 163
device storage 163
legal 163
phone usage 163
signal 163

inside screen 5

J

jack

3.5mm audio 4

K

keypad sounds

turning off 123
turning on 123

L

Language

changing 146

LED Flash 3

Lively Skill

setting up 84

M

Magnifier 97

Main Menu 11, 12

Contacts option 44

Device Info option 145

Main Menu options 12

Amazon Alexa 12

Contacts 12

Device Info 13

Games 13

Help Tools 13

Phone 12

Photos & Videos 13

Settings 13

Text Messages 12

Making a Call 23

microphone 3

Missed Calls 38

Mobile Support 115

N

Navigation

button 17

navigation buttons

text messages 61

Notification LED 3

Notifications

turning on/off 130

number buttons 62

number pad 6

O

Ok button 6, 17

outside screen 3, 5

P

period button

text messages 63

phone

Calling a Contact 24

dialing a number 23

hearing aid 145

information about 163

Main Menu 12

Making a Call 23

on-screen tips 148

overview 36

turning on/off 20

using text in call 135

Phone menu

Blocked Numbers option 47

Call History option 42

Contacts option 40

Dial Number option 43

Missed Calls option 38

Unblock Number option 49

Voicemail option 39

phone numbers 165

Support 115

Phone Overview 36

phone tools

alarm clock 98

Calculator 106

flashlight 96

FM Radio 108

Magnifier 97

stopwatch 104

timer 102

Photo

deleting 73

saving 69

taking 69

Photos

attaching to text message 75

deleting 73

sending 65, 75

sharing 75

taking 27

viewing 72

Photos & Video 67

Photos & Videos

Camera option 68

Main Menu 13

Overview 68

Photo/Video Gallery

option 68

Power Button 5

punctuation buttons

text messages 62

Q

Quick Text mode 63

R

Radio 108

Reading text messages 57

Read Out

turning on/off 143

Real Time Text

turning on/off 144

Rear Camera 3

Rear Speaker 4

rejecting calls 50

removing

photos 73

videos 73

removing text messages 66

replying to text messages 57

responding to text messages 57

ringer volume

adjusting 53

ring tone

adjusting volume 122

changing 121

selecting 121

RTT

turning on/off 144

S

screen 3

- inside 5
- outside 3
- sending**
 - photo 65
 - text messages 59
- Settings**
 - Main Menu 13
- Settings menu**
 - Accessibility 142
 - Bluetooth & Wi-Fi 136, 138
 - Color 152
 - Contacts Sort list 132
 - Emergency Alerts 149
 - Keypad Sounds 123
 - Lock Buttons 127
 - Notifications 130
 - Ring Tone 121
 - Text Mode 133
 - Tips 148
 - Urgent Response 118
- Voicemail 130
- Volumes & Sounds 121
- sharing**
 - photos 75
 - videos 75
- sounds**
 - keypad 123
 - ring tone 121
- space button**
 - text messages 61
- speaker**
 - earpiece 5
 - Rear 4
- Speakerphone**
 - button 51
 - turning on/off 51
- Speed Dial 45**
- status bar 10, 11, 14**
 - battery level 15
 - Bluetooth status 15

- cellular signal strength 14
- current time 15
- Urgent Response 15
- Wi-Fi status 14
- stopwatch**
 - using 104
- Storing the Speed Dial 45**
- support**
 - contact information 165
 - phone number 115
- T**
- taking photos 27, 69**
- text entry mode button**
 - text messages 63
- text messages 55**
 - attaching photos and videos 75
 - composing 25, 26
 - creating 25, 26
 - deleting 66
 - letter mode 64

- Main Menu 12
- notifications 130
- numeric mode 64
- overview 56
- Quick Text mode 63
- reading 57
- removing 66
- replying 57
- responding 57
- sending 59
- sending to a contact 25, 26
- sending to a phone number 25, 26
- special buttons 61
- typing with keypad 61
- viewing a list 57
- viewing history 57
- Text Mode**
 - 123 (numeric) 135
 - Abc (initial cap) 134

- abc (lowercase) 134
- ABC (uppercase) 135
- Quick Text 133
- selecting 133, 134, 135
- Text Size**
 - changing 142
- timer**
 - setting 102
- Tips**
 - turning on/off 148
- Title Bar 11, 16**
- U**
- unblock numbers 49**
- Urgent Response Service**
 - button 5, 6
 - turning on 33
 - turning on/off 118
 - using 119
- USB
 - cable 2, 7

- charging port 4
- V**
- video**
 - deleting 73
 - discarding 73
 - front camera 70
 - rear camera 70
 - recording 70
 - saving 70
 - viewing 72
- viewing**
 - photos 72
 - videos 72
- Viewing**
 - text messages 57
- voicemail 39**
 - listening to messages 39
 - notifications 130
 - setting greeting 29
- volume**

adjusting call 52, 124
adjusting headphone 125
adjusting ringer 53
adjusting ring tone 122
adjusting when locked buttons
128
button 3, 52
locking buttons 127

Volume Buttons

adjusting when locked 128
locking exterior 127

W

Wall Charger 2

Wi-Fi

connecting 30, 136
password 32
status 14

